

ITEM NO.: OLIVER FLOOR LAMP #212809

ASSEMBLY INSTRUCTIONS

PLEASE READ THOROUGHLY. MAKE SURE YOU PROPERLY ALIGN POLES BEFORE SCREWING THEM TOGETHER TO AVOID DAMAGING CONNECTION THREADS. NOT ADHERING TO THIS PROCEDURE MAY VOID YOUR WARRANTY.

Carefully unpack this lamp and place it on a flat surface.

1. Attach pole (5) with base (4) together, place screw (1) through the spring washer (2), dented washer (3) and base (4) to secure pole (5) with tool (tool included).
2. Connect the junction box (6) together with pole (5), (8) then secure it with screw (7).
3. Attach the shade (10), sleeve(11) onto socket (9) and secure it with ring (12).
4. Install the bulb (13) into socket (9).

Use 3pcs 60W (Maximum) Incandescent A Type Bulb. (Not included)

IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other) as safety a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

※ SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.

URBAN BARN

