ITEM NO: Gila Table Lamp White #219972 ASSEMBLY INSTRUCTIONS:

VERY IMPORTANT:

PLEASE READ THOROUGHLY. MAKE SURE YOU PROPERLY ALIGN POLES BEFORE SCREWING THEM TOGETHER TO AVOID DAMAGING CONNECTION THREADS.NOT ADHERING TO THIS PROCEDURE MAY VOID YOUR WARRANTY.

CAREFULLY UNPACK AND PLACE ALL PARTS ON A FLAT SURFACE.


- 1. Screw the socket assembly(A) to the body(B).
- 2. Screw tube(C) to socket assembly(A).
- 3. Place shade(D) onto tube(C) and screw finial(E) onto the top of shade(D).
- 4. Install bulb(F) into socket of socket assembly(A).
- 5. Insert the polarized plug into wall outlet, pull the chain to turn on the light and enjoy your new lamp.

USE 60W*2 (MAXIMUM) A TYPE BULB. (BULB NOT INCLUDED)

IMPORTANT SAFETY INSTRUCTIONS:

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF IT DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS THE PLUG CAN BE FULLY AND EASILY INSERTED. DO NOT ATTEMPT TO ALTER THE PLUG.

% SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.



URBAN BARN


ITEEM NO: Gila Table Lamp Black #219973 F VERY IMPORTANT: PLEASE READ THOROUGHLY. MAKE SURE YOU PROPERLY ALIGN POLES BEFORE Shade (D) SCREWING THEM TOGETHER TO AVOID DAMAGING CONNECTION THREADS.NOT ADHERING TO THIS PROCEDURE MAY VOID YOUR WARRANTY. Shade (D) CAREFULLY UNPACK AND PLACE ALL PARTS ON A FLAT SURFACE. 6. Screw the socket assembly(A) to the body(B). Socket A 7. Screw tube(C) to socket assembly(A). Socket A Socket A 8. Place shade(D) onto tube(C) and screw finial(E) onto the top of shade(D). 9. Install bulb(F) into socket of socket assembly(A). Socket assembly(A). 10. Insert the polarized plug into wall outlet, pull the chain to turn on the light and enjoy your new lamp. Bot

USE 60W*2 (MAXIMUM) A TYPE BULB. (BULB NOT INCLUDED)

IMPORTANT SAFETY INSTRUCTIONS:

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF IT DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS THE PLUG CAN BE FULLY AND EASILY INSERTED. DO NOT ATTEMPT TO ALTER THE PLUG.

% SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.



URBAN BARN